


## Endless possibilities

Changeable covers allow you express your style to every part of your space, cleverly inferring an individual style to the way you like.



# AvatarOn

Your space, your style



[se.com/vn/en](http://se.com/vn/en)

Life Is On

Schneider  
Electric

## AvatarOn Your space, your style

### Schneider Electric Vietnam

Email: [customer-care.vn@schneider-electric.com](mailto:customer-care.vn@schneider-electric.com)  
Website: [www.se.com/vn/en](http://www.se.com/vn/en)  
Toll Free: 1800-585858  
<https://www.facebook.com/SchneiderElectricVN>

[www.se.com/vn/en](http://www.se.com/vn/en)

© 2021 Schneider Electric. All Rights Reserved.

**Hanoi**  
8th Floor, Vinaconex building  
34 Lang Ha St., Dong Da Dist.  
Tel: (024) 38 314 037  
Fax: (024) 38 314 039

**Danang**  
6th Floor, ACB Tower  
218 Bach Dang St., Hai Chau Dist.  
Tel: (0236) 3 872 491  
Fax: (0236) 3 872 504

**Hochiminh**  
7th Floor, E-town 1 building  
364 Cong Hoa St., Tan Binh Dist.  
Tel: (028) 38 103 103  
Fax: (028) 38 120 477



## Unique & Innovative design

With revolutionary "SS" technology ensures a perfect and seamless movement of every switch that you have never experienced.



## The intimate LED

Night light merges seamlessly with dolly creating a stylish and streamlined design.



## Personalization functions

The key holder, cell phone holder and USB charging function give more convenience to your life.

Product Description	White Color	Wine Gold Color	Dark Grey Color	Dark Wood Color
<b>Switch</b>				
16AX 250V 1 Gang 1 Way Switch with LED	E8331L1LED_WE_G19	E8331L1LED_WG_G19	E8331L1LED_DG_G19	E8331L1LED_WD_G19
16AX 250V 2 Gang 1 Way Switch with LED	E8332L1LED_WE_G19	E8332L1LED_WG_G19	E8332L1LED_DG_G19	E8332L1LED_WD_G19
16AX 250V 3 Gang 1 Way Switch with LED	E8333L1LED_WE_G19	E8333L1LED_WG_G19	E8333L1LED_DG_G19	E8333L1LED_WD_G19
16AX 250V 4 Gang 1 Way Switch with LED	E8334L1LED_WE_G19	E8334L1LED_WG_G19	E8334L1LED_DG_G19	E8334L1LED_WD_G19
16AX 250V 1 Gang 2 Way Switch with LED	E8331L2LED_WE_G19	E8331L2LED_WG_G19	E8331L2LED_DG_G19	E8331L2LED_WD_G19
16AX 250V 2 Gang 2 Way Switch with LED	E8332L2LED_WE_G19	E8332L2LED_WG_G19	E8332L2LED_DG_G19	E8332L2LED_WD_G19
16AX 250V 3 Gang 2 Way Switch with LED	E8333L2LED_WE_G19	E8333L2LED_WG_G19	E8333L2LED_DG_G19	E8333L2LED_WD_G19
16AX 250V 4 Gang 2 Way Switch with LED	E8334L2LED_WE_G19	E8334L2LED_WG_G19	E8334L2LED_DG_G19	E8334L2LED_WD_G19
16AX 250V 1 Gang Intermediate Switch	E8331M_WE_G19	E8331M_WG_G19	E8331M_DG_G19	E8331M_WD_G19
20A 250V 1 Gang Double Pole Switch with LED	E8331D20N_WE_G19	E8331D20N_WG_G19	E8331D20N_DG_G19	E8331D20N_WD_G19
20A 250V 2 Gang Double Pole Switch with LED	E8332D20N_WE_G19	E8332D20N_WG_G19	E8332D20N_DG_G19	E8332D20N_WD_G19
32A 250V 1 Gang Double Pole Switch with LED	E8331D32N_WE_G19	E8331D32N_WG_G19	E8331D32N_DG_G19	E8331D32N_WD_G19
45A 250V 1 Gang Double Pole Switch with LED	E8331D45N_WE_G19	E8331D45N_WG_G19	E8331D45N_DG_G19	E8331D45N_WD_G19
4A 1 Gang Push Button	E8331PRL1_WE_G19	E8331PRL1_WG_G19	E8331PRL1_DG_G19	E8331PRL1_WD_G19
4A 2 Gang Push Button	E8332PRL1_WE_G19	E8332PRL1_WG_G19	E8332PRL1_DG_G19	E8332PRL1_WD_G19
4A 3 Gang Push Button	E8333PRL1_WE_G19	E8333PRL1_WG_G19	E8333PRL1_DG_G19	E8333PRL1_WD_G19
10A 2 Gang Mechanical Curtain Switch	E8332C_WE_G19	E8332C_WG_G19	E8332C_DG_G19	-
10A Bell Switch	E8331BPL1_WE_G19	E8331BPL1_WG_G19	E8331BPL1_DG_G19	E8331BPL1_WD_G19



Product Description	White Color	Wine Gold Color	Dark Grey Color	Dark Wood Color
<b>Cover</b>				
1 Gang Switch Cover	E8331_WE_G19	E8331_WG_G19	-	E8331_WD_G19
1 Gang Switch Cover with Keyholder	E8331KH_WE_G19	E8331KH_WG_G19	-	E8331KH_WD_G19
2 Gang Switch Cover	E8332_WE_G19	E8332_WG_G19	-	E8332_WD_G19
3 Gang Switch Cover	E8333_WE_G19	E8333_WG_G19	-	E8333_WD_G19
3 Gang Switch Cover with Keyholder	E8333KH_WE_G19	E8333KH_WG_G19	-	E8333KH_WD_G19
4 Gang Switch Cover	E8334_WE_G19	E8334_WG_G19	-	E8334_WD_G19



Product Description	White Color	Wine Gold Color	Dark Grey Color	Dark Wood Color
<b>Dimmer &amp; Sensor</b>				
250W 1 Gang Lighting Dimmer	E8331RD250_WE	E8331RD250_WG	E8331RD250_DG	-
Volume control, 5W, 8 Ohm	E8331VC_WE_G19	E8331VC_WG	-	-
Panic Button with Key Reset	E8331KPB_WE_G19	E8331KPB_WG_G19	E8331KPB_DG_G19	E8331KPB_WD_G19
Wall Light	E8390FLW_WE_G19	-	-	-
Air Quality Sensor	E83PM25	-	-	-



Product Description	White Color	Wine Gold Color	Dark Grey Color	Dark Wood Color
<b>Socket Outlet</b>				
10A 2 Gang 2 Pin Socket	E83426U2_WE_G19	E83426U2_WG_G19	E83426U2_DG_G19	E83426U2_WD_G19
16A 250V 1 Gang International Socket	E83426TS_WE_G19	E83426TS_WG_G19	E83426TS_DG_G19	-
16A 250V 1 Gang Switch International Socket	E8315TS_WE_G19	E8315TS_WG_G19	E8315TS_DG_G19	-
2 Gang USB Charger 2.1A	E8332USB_WE_G19	E8332USB_WG_G19	E8332USB_DG_G19	E8332USB_WD_G19
16A 250V 2 Gang 3 Pin Socket	E83426UES2_WE_G19	E83426UES2_WG_G19	E83426UES2_DG_G19	E83426UES2_WD_G19
16A 250V 1 Gang International Socket with 2 Gang USB Charger 2.1A.	E8342616USB_WE_G19	E8342616USB_WG_G19	E8342616USB_DG_G19	-



Product Description	White Color	Wine Gold Color	Dark Grey Color	Dark Wood Color
<b>Telecommunication Outlet</b>				
1 Gang TV Outlet	E8331TV_WE_G19	E8331TV_WG_G19	E8331TV_DG_G19	E8331TV_WD_G19
2 Gang TV Outlet	E8332TV_WE_G19	E8332TV_WG_G19	E8332TV_DG_G19	E8332TV_WD_G19
1 Gang Tel Outlet	E8331RJS4_WE_G19	E8331RJS4_WG_G19	E8331RJS4_DG_G19	E8331RJS4_WD_G19
2 Gang Tel Outlet	E8332RJS4_WE_G19	E8332RJS4_WG_G19	E8332RJS4_DG_G19	E8332RJS4_WD_G19
1 Gang Data Cat5e Outlet	E8331RJS5_WE_G19	E8331RJS5_WG_G19	E8331RJS5_DG_G19	E8331RJS5_WD_G19
2 Gang Data Cat5e Outlet	E8332RJS5_WE_G19	E8332RJS5_WG_G19	E8332RJS5_DG_G19	E8332RJS5_WD_G19
1 Gang Data Cat6 Outlet	E8331RJS6_WE_G19	E8331RJS6_WG_G19	E8331RJS6_DG_G19	-
2 Gang Data Cat6 Outlet	E8332RJS6_WE_G19	E8332RJS6_WG_G19	E8332RJS6_DG_G19	-
TV + Data Cat5e Outlet	E8332TVRJS5_WE_G19	E8332TVRJS5_WG_G19	E8332TVRJS5_DG_G19	E8332TVRJS5_WD_G19
Tel + Data Cat5e Outlet	E8332TDRJS5_WE_G19	E8332TDRJS5_WG_G19	E8332TDRJS5_DG_G19	E8332TDRJS5_WD_G19
TV + Data Cat6 Outlet	E8332TVRJS6_WE_G19	E8332TVRJS6_WG_G19	E8332TVRJS6_DG_G19	-
HDMI + USB Outlet	E8332HDUSB_WE_G19	E8332HDUSB_WG	E8332HDUSB_DG	-
VGA + mini Audio Outlet	E8332HD15PH_WE_G19	E8332HD15PH_WG_G19	E8332HD15PH_DG_G19	-
2 Gang HDMI Outlet	E8332HDHD_WE_G19	E8332HDHD_WG	E8332HDHD_DG	-
HDMI + RJ45 Data Cat5e	E8332HDRJS5_WE_G19	E8332HDRJS5_WG_G19	E8332HDRJS5_DG_G19	-
25A 250V 1 Gang Connection Unit	E8331TB_WE_G19	E8331TB_WG_G19	E8331TB_DG_G19	E8331TB_WD_G19
13A 250V 1 Gang Fused Connection Unit	E8330FSG_WE_G19	E8330FSG_WG_G19	E8330FSG_DG_G19	E8330FSG_WD_G19
13A 250V 1 Gang Fused Connection Unit With Neon	E8330FSGN_WE_G19	E8330FSGN_WG_G19	E8330FSGN_DG_G19	E8330FSGN_WD_G19
13A 250V 1 Gang Fused Connection Unit With Double Pole Switch and LED	E8331DFSGN_WE_G19	E8331DFSGN_WG_G19	E8331DFSGN_DG_G19	E8331DFSGN_WD_G19



Product Description	White Color	Wine Gold Color	Dark Grey Color	Dark Wood Color
<b>Hotel Series</b>				
Shaver Unit	E83T727V_WE_G19	E83T727V_WG_G19	E83T727V_DG_G19	E83T727V_WD_G19
250V 16A Electronic Key Card Switch	E8331EKT_WE_G19	E8331EKT_WG_G19	E8331EKT_DG_G19	E8331EKT_WD_G19
250V 16A Electronic Key Card Switch with Identification	E8331EKTID_WE	E8331EKTID_WG	E8331EKTID_DG	-
DND, PCU, PW Indicator with Bell Switch	E8331BPDMMW_WE_G19	E8331BPDMMW_WG_G19	E8331BPDMMW_DG_G19	E8331BPDMMW_WD_G19
3 Gang Switch with PCU, DND, PW Symbol	E8333DMWS_WE_G19	E8333DMWS_WG_G19	E8333DMWS_DG_G19	E8333DMWS_WD_G19
2 Gang Switch with PCU, DND Symbol	E8332DMS_WE	E8332DMS_WG	E8332DMS_DG	-
Door Bell	99AC220	99AC220	99AC220	99AC220



Product Description	White Color	Wine Gold Color	Dark Grey Color	Dark Wood Color
<b>Accessories</b>				
1 Gang Blank Plate	E8330X_WE_G19	E8330X_WG_G19	E8330X_DG_G19	E8330X_WD_G19
1 Gang Wall Box	A3B050_G19	A3B050_G19	A3B050_G19	A3B050_G19
WP 1 Gang Cover for Socket, IP55	E223R_TR	E223R_TR	E223R_TR	E223R_TR
WP Twin Gang Cover for Socket, IP55	ET223R_TR	ET223R_TR	ET223R_TR	ET223R_TR
WP 1 Gang Cover for Switch, IP 55-	E223M_TR	E223M_TR	E223M_TR	E223M_TR

